

BF901 FITTING INSTRUCTIONS



1. Cut out in bottom of unit to allow foot operated mechanism to be fitted behind telescopic shroud.
2. Attach the bottle filler supply pipe to the elbow on the top of the bottle filler outlet - this is a push fit and needs to be securely pushed into the fitting.
3. The foot plate is supplied loose for safety in transport. The foot valve is loosely fitted to the foot plate. Tighten the foot valve - the securing nut is under the chrome fascia cover. The foot plate is secured to the floor/wall with bolts.
4. The supply pipework goes through the telescopic shroud and connects to your supply pipework behind the bottle filler.
5. Connect waste fitting.
6. Hook bottle filler to the wall using rear keyhole wall fixing points.
7. Secure using wall fixing points at bottom of unit.
8. The bottom of the telescopic shroud slots into the foot plate, the top cover then fits over the bottom and up to the bottle filler and is secured to the wall through the screw holes at each side.
9. Check all inlet and outlet connections for leaks.
10. Remove protective coating and thoroughly clean the unit with warm soapy water and a clean cloth. **All further cleaning should only be undertaken with warm soapy water.**

All installation advice provided in these instructions are offered as an opinion only and the customer accepts such opinions at their sole discretion and risk.