

## **Installation and Maintenance Instructions**

### **Apinox Product Code 240 Wash Basin**

#### **Installation**

The wash basin is supplied in two (2) sections, the basin top and the apron support. Assemble the two sections together with the screws provided.

To install the wash basin offer the unit to the wall at the desired height and, after ensuring that the unit is level, carefully mark the position of the screw holes in the rear upstand and the screw holes in the apron support (underneath). Remove the basin, drill and plug the holes and secure the basin firmly to the wall using a suitable (non corroding) fastener.

Fit any taps as required into the tap holes provided.

Fit the waste to the basin, and make all plumbing connections

#### **Earthing Continuity**

All basins are provided with a number of fixing points on to which an earthing continuity wire with an end terminal can be secured.

#### **Maintenance**

Routine cleaning is necessary to maintain the appearance of stainless steel. Washing with soap or a mild detergent and warm water, applied with a sponge or bristle brush, followed by a clear water rinse is all that is required.

For further information please see our 'Care and Maintenance of Stainless Steel' leaflet.